# **7** THINGS TO DO BEFORE SENDING OIL SAMPLES **TRIC**



# FILL BOTTLE TO TOP

Trico requires a full bottle for accurate oil analysis and verification testing. Please hand tighten cap. Do not use tape on cap for a seal.

### AFFIX LABEL OVER QR CODE

Affix label over QR code, if the mobile app is not being used. If no label is available, please see step 4. If mobile is desired, see step 6.



2.

4.

6.

### FOR RUSH SAMPLES

Notify us if the sample requires an expedited analysis or special attention.

LABEL

### SAMPLES NOT IN OUR DATABASE

Submit lubricant name (ex - Shell Omala S4 GX 320) Submit reservoir capacity (ex - 10 gallons)

### SHIP BOTTLES UPRIGHT TO:

5. LABEL

Trico, Attn: Oil Analysis 1235 Hickory St, Pewaukee, WI 53072 *Keep any empty bottles for next sampling. If extra shipping boxes are needed contact us.* 

# DOWNLOAD MOBILE APP



Contact us, and we'll help you set up your account for our mobile app.







# **NEED HELP! SCAN QR CODE FOR RESOURCES**

Scan QR code to visit webpage or you can reach us by phone at (262) 691-9336 or email oilanalysiscs@tricocorp.com.